



### Features and Benefits

- Slim design for room applications
- Easy installation with LED indication
- Supports 2-wire loop powering or 3-wire installation
- Built-in circuitry diagnostics
- Optional set point, momentary button and LCD available

### Technical Overview

The TT-S-ACT uses a high accuracy 10K3A1 thermistor element, and offers options such as set point adjust & momentary switch, together with a backlit LCD display.

A 0-10Vdc override status input option is also available, allowing occupancy indication on the display.

A feature of this sensor is when in 3-wire mode it automatically detects the controller input type, 4-20mA or 0-10Vdc. This can be overridden via a DIP switch if required, also 2-wire loop powering (4-20mA) is also selectable via DIP switch. Sensors have on-board LED indication for power up status, output mode type and useful self-test feature.

### Product Codes

<b>TT-S-ACT</b>	Space temperature transmitter $\pm 0.3^{\circ}\text{C}$
Suffixes (add to part code)*	
<b>-SP</b>	2-Wire resistive set point 0-10k $\Omega$ or 11-1k $\Omega$
<b>-MS</b>	Momentary switch
<b>-LCD</b>	Integral LCD
<b>-TR</b>	Custom temperature output range scaling
<b>-5V</b>	Output 0-5Vdc (instead of 0-10Vdc)

### Accessories

<b>DECOR</b>	Decorators trim plate
<b>GASKET</b>	Insulating gasket (pack of 10)

### Specification

Outputs:	
3-wire	0-10Vdc (0-5V for -5V) or 4-20mA
2-wire	4-20mA, loop powering
Power Supply:	24Vac/dc $\pm 10\%$ (3-wire)
	24Vdc $\pm 10\%$ (2-wire)
Supply current:	30mA (3-wire) max.
Electrical connections	Pluggable spring loaded terminal block min. 0.2mm <sup>2</sup> , max. 1.5mm <sup>2</sup>
Output range	0 to 40 $^{\circ}\text{C}$
Accuracy	$\pm 0.3^{\circ}\text{C}$
Environmental:	
Housing:	-10 to 60 $^{\circ}\text{C}$
	0 to 95% non-condensing
Housing:	
Material	ABS (flame retardant)
Dimensions	115 x 85 x 30mm
Protection	IP30
Country of origin	UK
Conformity	EMC, CE & UKCA Marked

If using the -LCD option, when in loop powered mode the back light will not be lit. The transmitter will require a 0V connection for the back light to work (3-wire).

### WEEE Directive:



At the end of the products useful life please dispose as per the local regulations. Do not dispose of with normal household waste. Do not burn.



## Installation



Antistatic precautions must be observed when handling these sensors. The PCB contains circuitry that can be damaged by static discharge.

1. Select a location on a wall of the controlled space which will give a representative sample of the prevailing room condition. Avoid sitting the sensor in direct sunlight, on an outside wall or near heat sources. An idea mounting height is 1.5m from the floor.
2. Undo the tamperproof screw at the bottom of the housing and remove the front panel from the base.
3. Using the base as a template mark the hole centres and fix to the wall with suitable screws. Alternatively the base plate can be mounted on to a conduit box or standard recessed back box. The base plate is suitable for EU & North America fixings.
4. Feed cable through the hole in the base plate of the housing, unplug the terminal block from the PCB and terminate the cores at the loose terminal block. Leave some slack inside the unit as required.
5. Set the switch on the PCB either to the 3-wire or 2-wire position. Please refer to "Selecting output mode and LED indication" for more details.

**IMPORTANT** Do not alter the switch position while sensor is powered up. Do not select 2-wire if a 0v connection (3-wire) is made. Permanent damage to the sensor or BMS controller may result.

**IMPORTANT** Ensure the Terminal Block is fitted the correct position and direction. The cable entry faces the centre of the sensor.

6. Connect all sensor outputs to the controller inputs or to the device, the sensor output(s) are connected to.
7. Before powering the sensor, ensure that the supply voltage is within the specified tolerances.

**IMPORTANT** Make all electrical output connections before applying the supply voltage. If the sensor is not connected in this sequence, damage may be caused to the input circuitry of the controller or device the sensor output(s) are connected to.

8. Allow 3 minutes before checking functionality, and at least 30 minutes before carrying out pre-commissioning checks. This will allow the electronics time to stabilise.

## Terminal Block:

For easier installation, the terminal block can be detached from the PCB.

When used with ferrules it doesn't require any tools to release the spring loaded terminal block. When used with stranded cable, push in the orange latch to compress the spring load. Feed in the wire and release the spring to secure the wire connection.

**IMPORTANT** Make sure the Terminal Block is fitted the correct position and direction. The cable entry faces the centre of the sensor.


## Electrical Connections:

<b>24V</b>	Supply 24Vac/dc
<b>0V</b>	Supply 0V (Common 0V)
<b>OP1</b>	Temperature output
<b>OP2</b>	Not used
<b>OP3</b>	Not used
<b>0V</b>	Not used
<b>TH1</b>	Not used
<b>TH2</b>	Not used

<b>FS1</b>	Not used
<b>FS2</b>	Not used
<b>P5</b>	Set point
<b>P6</b>	Set point, wiper
<b>P7</b>	Set point
<b>MS1</b>	Momentary switch
<b>MS2</b>	Momentary switch
<b>OVR</b>	Override on LCD



## LED Indication:

LOOP	Blue
4-20mA	Yellow
0-10V	Green
ERROR	Red





### Electrical Connections (continued)



3-wire, 0-10Vdc / (0-5Vdc optional):



3-wire, 4-20mA:




2-wire, 4-20mA:



See next page for further information on setting output modes.

-T, direct resistive output:



**Momentary switch (-MS):**  
max. 500mA @24Vac/dc

**Set point (-SP):**

	-	+
P5/ P6	0k $\Omega$	10k $\Omega$
P7/ P6	11k $\Omega$	1k $\Omega$

For 1-11k $\Omega$  use the 0-10k $\Omega$  and add an inline 1k $\Omega$  resistor on the controller input side

### Selecting output mode and LED indication:

**IMPORTANT** Do not alter the switch position while sensor is powered up. Do not select 2-wire if a 0v connection (3-wire) is made. Permanent damage to the sensor or BMS controller may result.

#### 3-wire connection:

Ensure there is no power to the sensor before changing the switch. Set the switch in the left hand position. The sensor automatically sets the outputs to 0-10V or 4-20mA based on the resistive load on the outputs. All outputs MUST be connected to the same type of load:

- If ALL the loads are  $>2k\Omega$ , all the outputs will be set to 0-10Vdc and the green 0-10V LED will light.
- If ALL the loads are  $>50\Omega$  and  $<550\Omega$ , all the outputs will be set to 4-20mA and the yellow 4-20mA LED will light.
- If ANY of the loads are  $<50\Omega$  or  $>550$  and  $<2k\Omega$ , all the outputs will be switched off and the red ERROR LED will light

Auto detection can be overridden via 2-way DP switch situated on the left hand side of the PCB.

Set the auto detection 2-way DIP switch to the **3-wire** position

Set the override 2-way switch to:

- Voltage (0-10V/0-5V) switch DIP1 (V) to ON
- Current (4-20mA) switch DIP2 (I) to ON

### Selecting output mode and LED indication (continued):

The ON position for the switch is labelled on the switch itself.

Example, if you set the V switch (left) to OFF and the I switch (right) to ON, the device will force 3-wire current mode. The device is also set up to detect a change on these switches and reboot itself after 5 seconds - the error LED will flash during this period then the yellow 4-20mA LED will illuminate.

#### 2-wire connection:

Ensure there is no power to the sensor before changing the switch and do not connect 0V. Set the switch in the right hand position. All outputs MUST be connected. The blue LOOP LED will light.

The LEDs will switch off after 15 minutes.


#### Self-Test Button:

The self-test button helps the installer to validate the wiring for each output and helps to commission the system.

When self-test button is pushed it cycles all outputs as follows: 0%, 50%, 100%, normal operation. After 30 seconds in any mode the system resets to normal operation.

When self-test button is held for more than 3 seconds, it sets all outputs to 50%, when released the outputs return to normal operation.

#### Dimensions:



#### Revision History:

Rev.	Description of change	Page No.	Date
7.3	Output type override & dimensions	3, 4 & 5	26/06/2022
7.2	UKCA added	1	01/10/2021
7.1	LED status	4	31/01/2020
7.0	New product	All	24/09/2019

Whilst every effort has been made to ensure the accuracy of this specification, Sontay cannot accept responsibility for damage, injury, loss or expense resulting from errors or omissions. In the interest of technical improvement, this specification may be altered without notice.