



Features and Benefits

- Weatherproof Housing
- Wide range of sensing element types
- Optional probe lengths, 2m or 5m
- Hinged lid with the facility of tamper proofing

Technical Overview

True duct averaging sensors use a PT100b sensing element that measures along the full length of the copper tube apart from the first 100mm.

The -CVO active output option combines 4 pre-set ranges and selectable output mode, customised output range scaling enabling a choice of outputs and ranges on one unit.

Product Codes

TT-TDA True Duct Averaging Sensor

Sensing Element (add type to above code)
Passive output:

-PT100B (PT100a)

Active output:

-CVO 4-20mA/0-10Vdc selectable output
-CVO-C 4-20mA/0-10Vdc selectable output with
custom temp. scaling -10 to +100°C

Specification

Output types:	Passive	Resistive
	Active (selectable)	Current 4-20mA or Voltage 0-10Vdc
Accuracy:	PT100b	±0.425°C @ 25°C
	-CVO	±0.625°C @ 25°C
Probe:	Material	Copper
	Dimensions	2.05m x ¼" dia.
Housing:	Material	PC/GF (Halogen free, flame retardant & UV stabilized)
	Dimensions	125 x 105 x 85mm
Protection		IP65
Environmental:	Housing:	-30 to 70°C
	Media:	0 to 95% non-condensing -10 to +100°C
Weight		420g
Country of origin		UK
Conformity (CVO types only)		EMC, CE & UKCA Marked

WEEE Directive:



At the end of the products useful life please
dispose as per the local regulations.
Do not dispose of with normal household waste.
Do not burn.



Installation

1. Select a location in the duct where the sensor probe will give a representative sample of the prevailing air condition.
2. Drill a 8.5mm diameter hole in the duct, then use the housing as a template mark the hole centres, drill and fix the housing to the duct.
3. Release the snap-fit lid by gently squeezing the locking tab.
4. Feed the cable through the waterproof gland and terminate the cores at the terminal block. Leaving some slack inside the unit, tighten the cable gland onto the cable to ensure water tightness.
5. If the sensor is to be mounted outside, it is recommended that the unit be mounted with the cable entry at the bottom. If the cable is fed from above then into the cable gland at the bottom, it is recommended that a rain loop be placed in the cable before entry into the sensor.
6. Snap shut the lid after the connections have been made.

Connections


All connections to BEMS controllers, data recorders etc. should be made using screened cable. Normally, the screen should be earthed at one end only (usually the controller end) to avoid earth hum loops which can create noise. Low voltage signal and supply cables should be routed separately from high voltage or mains cabling. Separate conduit or cable trays should be used. Where possible, the controller's earth should be connected to a FUNCTIONAL EARTH, rather than the mains safety earth. This will provide better immunity to high frequency noise. Most modern buildings have a separate earth for this purpose.

Passive output:



Connections are made via the 2-way terminal block. Connections for thermistor, platinum and nickel sensing elements are polarity independent.

Active output:



* Not required with 4-20mA output

Notes: Voltage output Nominal voltage 24Vac/dc.
Current output If using in current output mode, the sensor must only be used with a 24Vdc supply. The sensor may be damaged if supplied with AC.

The selectable output temperature ranges are dependent on sensor type, ambient and application. For full connection and specification please refer to the TT-CVO data sheet.

Whilst every effort has been made to ensure the accuracy of this specification, Sontay cannot accept responsibility for damage, injury, loss or expense resulting from errors or omissions. In the interest of technical improvement, this specification may be altered without notice.